

# **Steeda Intake Spacer**

## **Ford Fusion**

### **3.0L V6 and 2.3L 4 Cylinder**

#### **Instructions for Part # 555-3132 and 555-3133**

1. Start by disconnecting the intake tube that connects to the throttle body from the mass air meter.
2. Unbolt the throttle body and place it off to the side.
3. The Steeda intake spacer requires the use of 2 supplied gaskets, one on the front and one on the back of the spacer. Using the supplied 6mm bolts, bolt up the throttle body with the Steeda intake spacer bolted between the throttle body and the intake manifold, Pic 2. Reconnect the intake tube and you are finished!