

# **STEEDA**

## **FUSION STRUT TOWER BRACE**

Installation Instructions for Part #:555-5720

- 1) Remove the two nuts on each strut tower which are closer to the firewall. It is not necessary to remove the third (inner) nut.
- 2) Set the strut tower brace on the car with the holes in the end brackets over the studs on the strut tower.
- 3) Reinstall the nuts on the strut tower, over the strut tower brace brackets. Torque nuts to 18 ft-lb. (25 Nm).
- 4) Screw the cap back onto the brake fluid reservoir if removed.

Steeda Autosports Inc. All Rights Reserved 2006 *STBFusion.doc* 8/06